



SAFETY & STYLE

Camino Gral. Belgrano KM 10.5.
Bernal, Buenos Aires, Argentina.



FRONT



BACK

PRODUCT SPECIFICATION

Particulate Respirator

1. Product Code: 42CFR84 (**SBMASCARA0**)
2. Description: Respiratory protection mask.
3. Specifications:

Material: Polypropylene (PP)

Color: White

Valve: No

Weight: 0.05 kg

Extra: External nose clip for optimal fit, soft foam inner nose pad. Synthetic latex rubber headband.



APPLICATIONS

USE AGAINST:

NIOSH approved for protection against particulate aerosols free of oils. JFY recommends this respirator for use against particulate such as flour, iron coal and minerals.

DO NOT USE AGAINST:

1. Vapors, paint spray, oil-based aerosols, asbestos an sand blasting.
2. Any contaminant whose concentration is unknown, or immediately dangerous to life.
3. Concentrations of dust and mists which exceed the maximum use concentration or 10 times contaminant's permissible exposure limit established by OSHA.

WARNING:

1. These respirators do not supply oxygen. Use only in well ventilated areas containing sufficient oxygen to support life.
2. Leave contaminated area immediately if the respirator becomes damaged and proper fit cannot be obtained or breathing becomes difficult. Dispose and change the respirator.
3. The respirator has been tested. Small punctures around the staples are normal and do not interfere with the respirator compliance with Part 84 approval requirements. However, it is subject to inspector prior to each use to assure there are no holes in the breathing zone other than the punctures around staples and no damage has occurred. Enlarged holes resulting from ripped or torn filter material around staples punctures are considered damage.

IMPORTANT LIMITATIONS:

1. All instructions and warnings have to be followed. Failure to do so will reduce the efficiency of the respirator and cause sickness or death.
2. Training on the proper use of respirator must be provided by the employed in accordance with the safety and heath standard.
3. Before occupational use of this respirator, a written respiratory protection program must be implemented meeting all the local government requirements. In the Unite States, employers must comply with OSHA 29 CFR 1910.134 which includes medical evaluation, training, and testing.
4. Do not alter or modify the respirator.
5. Not suitable for persons with bear or the facility hair which may reduce the efficiency of respirator.
6. The use and reuse of this respirator is subject to consideration of hygiene damage and increased breathing resistance. Service time should not be extended beyond 8 total hours of use.
7. S-Special or critical user instructions: the model SBMASCARA0 filtering facepiece respirator has been manufactured by JINFUYU INDUSTRIAL CO., LTD. for SAFETY & STYLE SRL. Under TC-84A-3888.



Sebastian Boris

SAFETY & STYLE

FILTERING FACEPIECE APPROVAL LABEL



SAFETY & STYLE SRL
 CAMINO GRAL. BELGRANO KM 10.5 BERNAL
 BUENOS AIRES, ARGENTINA
 5491142700913



THIS RESPIRATOR IS APPROVED ONLY IN THE FOLLOWING CONFIGURATION:

TC-	Protection ¹	Respirator	Cautions and Limitations ²
		SBMASCARA0	
84A-3888	N95	X	ABCJMNOPS

1. Protection

N95- Particulate Filter (95% filter efficiency level)
 effective against particulate aerosols free of oil;
 time use restrictions may apply

2. Cautions and Limitations

- A- Not for use in atmospheres containing less than 19.5% oxygen.
- B- Not for use in atmospheres immediately dangerous to life or health.
- C- Do not exceed maximum use concentrations established by regulatory standards.
- J- Failure to properly use and maintain this product could result in injury or death.
- M- All approved respirators shall be selected, fitted, used, and maintained in accordance with MSHA, OSHA and other applicable regulations.
- N- Never substitute, modify, add, or omit parts. Use only exact replacement parts in the configuration as specified by the manufacturer.
- O- Refer to User Instructions, and/or maintenance manuals for information on use and maintenance of these respirators.
- P- NIOSH does not evaluate respirators for use as surgical masks.
- S- Special or critical User Instructions and/or specific use limitations apply. Refer to User Instructions before donning.

WARNING:

NIOSH APPROVED: N95 95% filtration efficiency against solid and liquid aerosols that do not contain oil.

This respirator helps protect against certain particulate contaminants but does not eliminate exposure to or the risk of contracting disease or infection. Misuse may result in sickness or death.

Important notice to purchaser:

The following warranty is made in lieu of all other warranties expressed or implied, including but not limited to, the implied warranties of merchantability and fitness for purpose. Manufacturer's only obligation shall be, at our option, to replace any portion proving defective or to refund the purchase price thereof. User shall determine the suitability of the product for his intended use, and assume all risks and liability in connection therewith.